

## Precautions

1. Always exercise care when operating and handling.
2. Do not disassemble any portion of the charger and adapter as this will void any product warranty.
3. Do not use any power adapter other than the one provided with the device or acquired from the manufacturer or its partners.
4. In the unlikely event that abnormal noise, strange odor, or smoke is present, immediately disconnect all power sources. Please report the problem to your device provider immediately.

## Specifications

I/O Ports	
DC-in	1
Charging Slot	6

Mechanical and Environmental	
AC/DC Adapters	Input: 100 to 240V AC; Output: 19V DC, 10.52A
Dimensions (H x W x D)	3.2 x 12.6 x 6.2 in/ 81.6 x 321 x 157.6 mm
Weight	2.86 lbs/ 1.3 kg
Regulatory	FCC Class B, CE, C-Tick, RoHS compliant
Temperature	Operation: 0°C to 40°C; Storage: -20°C to 60°C
Humidity	0% to 90% non-condensing

\*Specifications subject to change without notice.

## GC596

### BASIC OPERATION GUIDE

#### ENGLISH



#### INTRODUCTION

The GC596 6-Bay Gang Charger Kit (ACC-001-596) charges the hot-swappable DR202 batteries for the DT590, DT592, and DT594 series Medical Cart Computers. The Kit includes one battery cradle, an AC-DC adapter, and a power cord.

The battery cradle features a DC-input jack, six battery slots, and six LEDs for power and charging indicators. Connect the AC-DC adapter cable to the DC-input jack and then insert the battery packs in the correct direction into each slot for charging.

After inserting the battery pack in the slot, the charging LED lights up (orange) if the battery pack is being recharged. When charging is complete or if the battery pack is already fully charged, the LED will show solid blue.

#### LED Indicator Status

- Power On/ Off: LED off
- Battery Fully Charged: Blue
- Charging Battery: Orange
- Battery no longer good: Blinking Orange



#### Package Contents

1. One GC596 6-Bay Gang Charger
2. One AC-DC adapter with power cord

