

Desktop Charging Cradle

BASIC OPERATION GUIDE

Thank you for purchasing the Desktop Charging Cradle (ACC-008-99) by DT Research, available for charging one (1) DT370CR or DT380CR Rugged Tablet. The Desktop Charging Cradle features one (1) DC-input jack, one (1) LAN port, one (1) HDMI-output port, and four (4) USB ports.



Instructions:

Connect the AC-DC adapter cable to the DC-input jack, and then insert the Tablet system properly for charging.

CAUTION:

This charger must only be used with the specific tablet models for which it is designed. Failure to do so may result in battery or charger damage, or personal injury.

Package Contents:

- 1. Desktop Cradle
- 2. Basic Operation Guide

Precautions

- 1. Always exercise care when operating and handling.
- 2. Do not disassemble any portion of the charger and adapter, as this will void any product warranty.
- 3. Do not use any power adapter other than the one provided with the device or acquired from the manufacturer or its partners.
- 4. In the unlikely event that abnormal noise, strange odor, or smoke is present, immediately disconnect all power sources. Please report the problem to your device provider immediately.

Back View



LAN Port

Side View



Specifications

I/O Ports	
DC-in Jack	1
LAN Port	1
HDMI	1
USB Ports	4 (2 on the back panel, 1 on the left side, 1 on the right side)
Mechanical and Environmental	
AC/DC Adapter*	Input: 100 – 240V AC; Output: 12V DC, 5A
Dimensions (H x W x D)	1.93 in x 7.13 in x 6.10 in / 49.1 mm x 179.7 mm x 151.3 mm
Weight	1.39 lbs / 630 g
Temperature	Operation: 0°C – 40°C; Storage: -20°C – 60°C
Humidity	0% – 90% non-condensing

* The AC/DC Adapter is not included in the standard package.

** Specifications subject to change without notice.

CAUTION:

Only use the Power Adapter that is provided from DT Research. The power adapter, charger, and the tablet may become hot during normal use. Allow for proper ventilation around the power adapter, charger, and charging tablet. Never force a tablet into a charging bay. Check for any obstructions before insertion.



DT Research, Inc.

2000 Concourse Drive, San Jose, CA 95131 http://www.dtresearch.com Copyright © 2019, DT Research, Inc. All Rights Reserved.