

DT391 Tablet Series VESA Mount Cradle

BASIC OPERATION GUIDE



INTRODUCTION

Thank you for acquiring one of DT Research's tablet accessories – the DT391 Series VESA Mount Cradle. Featuring robust ABS plastic, these Cradles provide secure placement and charging of DT391 Series Rugged Tablets on VESA-compliant stands, brackets, and arms. The innovative design promotes ergonomic and efficient use of the tablets.

Package Contents

- One (1) DT391 Series VESA Mount Cradle
- One (1) VESA Conversion Bracket
- Eight (8) M4 Screws

OPERATION

Mounting the Cradle

The VESA Mount Cradle supports VESA standard mounting options (75 mm x 75 mm). Mount the cradle on a stand, bracket, or VESA arm.

*** NOTE:** If your stand or arm is 100 x 100 VESA, the VESA Conversion Bracket is needed. Please place the VESA Conversion Bracket on the back side of the Cradle, and apply the four M4 screws.

Inserting the Tablet into the Cradle

1. Push the latch on the back of the cradle to release its Top Clasp.
2. Insert the bottom part of the Tablet into the cradle with the prongs lined up correctly.
3. When the bottom of the Tablet is in place, push the Tablet against the back and into the cradle.
4. Push down on the Top Clasp so the top portion of the cradle slides down and locks into the locked-down position.



Releasing the Tablet from the Cradle

1. Push the latch to release its Top Clasp.
2. Using two hands, hold the Tablet on both sides, pull up and the top portion of the cradle will pull up simultaneously.
3. Remove Tablet from the Cradle.