

SPECIFICATIONS

System	
Processor	Intel® Atom™ Z530, 1.6GHz
Memory (RAM)	2GB
Storage	2GB to 32GB Flash
Operating Systems	Microsoft® Windows® Embedded Standard 7, Windows® 7 Professional, Windows® XP Embedded, Windows® XP Pro for Embedded Systems, or Linux
Display	7" LED-backlight screen with resistive touch; sunlight-readable option
Display Resolution	1024 x 600 (WSVGA)
Network Interface	Wi-Fi 802.11a/b/g/n, Bluetooth 2.1 with EDR
Control Switch and Buttons	1 power button, 5 front buttons and 1 trigger button
Indicator	1 power/ battery status LED and 1 WLAN active LED
Speaker/Microphone	Built-in speaker; built-in internal microphone
Input/Output Ports	1 DC-in Jack; 1 USB 2.0 port; 1 Headphone-out Jack combined with microphone
Power	
AC/DC Adapter	Input: 100 – 240V AC; Output: 19V DC, 2.36A
Battery Pack	Removable 7.4V, 3760mAh
Mechanical	
Enclosure	ABS + PC plastics
Stylus	Non-electronic tip
Protective Bumpers	Rubber bumpers on each corner for handling protection
Dimensions (H x W x D)	7.4 x 9.3 x 1.6 in/ 190 x 237 x 41 mm
Weight	2.43 lbs/ 1.1 kg
Environmental	
Water and Dust Resistance	IP65 * IP65 rating may not be applicable for units with module options
Vibration and Shock Resistance	MIL-STD-810G
Regulatory	FCC Class B, CE, C-Tick, RoHS compliant
Temperature	Operation: 0°C - 40°C; Storage: -20°C - 60°C
Humidity	0% - 90% non-condensing

* Specifications subject to change without notice.

DT372

BASIC OPERATION GUIDE



ENGLISH

INTRODUCTION

Thank you for acquiring the latest addition to DT Research's line of mobile tablets— the DT372. Featuring an IP65-rated, slim yet robust enclosure, the two-pound DT372 with 7" TFT display is powered by the Intel® Atom™ processor, offering optimal combinations of performance and power savings.

The DT372 is available with Windows® Embedded Standard 7, Windows® XP Embedded, Windows® XP Pro for Embedded Systems, Windows® 7 Pro or Linux operating systems.

Each software operating system features web browser, client/server computing software, media player, accessories, and applications support.

PACKAGE CONTENTS

- DT372 with Removable Battery Pack, Stylus with lanyard, and Bumpers
- AC-DC Power Adapter with Power Cord
- Handstrap
- Basic Operation Guide

Major options, depending on configuration:

- Desktop Charging Cradle with DC-in Power Jack, Ethernet, and USB Port
- Vehicle/ Wall mount cradle

* If your DT372 contains MSR, camera or scanner module, please refer to the POS module operation guide for detailed operation.

The DT372 (without handstrap)



Input/ Output Ports

A	DC Power Input
B	USB Port
C	Headphone Jack

Button Functions

BUTTON	ACTION
1	Battery swap suspend mode
2	Programmable, launch soft (on-screen) keyboard (default)
3	Launch SAS (Secure Attention Sequence) Generate Ctrl+Alt+Del keys to invoke the security windows defined under Windows XP
4	Programmable, Change display orientation (portrait/ landscape) (default)
5	Programmable, system utility menu (default)
6	Power on, Push/release typically enters Standby mode, or Push/release exits Standby mode or restarts device (software dependent) Push and hold (over 4 seconds) invokes hardware shutdown
7	Programmable, As scanner trigger when equipped with the scanner module

Power/Battery LED Status:

- Blue indicates the battery is 25% to 100% charged
- Blinking blue indicates the battery is charging
- Orange indicates that the battery is between 11% to 25%
- Blinking Orange indicates that the battery is below 10%

Precautions

- Always exercise care when operating and handling the DT372.
- Do NOT apply excessive pressure to the display screen.
- We recommend using the Stylus provided to keep the screen clean.
- Avoid prolonged exposure of the display panel to any strong heat source. Wherever possible, the DT372 should face away from direct light to reduce glare.
- If the AC-DC power adapter is used to recharge or power the device, do NOT use any AC-DC adapter other than the one provided with the device or acquired from the manufacturer or its partners.
- In the unlikely event that smoke, abnormal noise, or strange odor is present, immediately power off the DT372 and disconnect all power sources. Report the problem to your device provider immediately.
- Never attempt to disassemble the DT372, as this will void the warranty.

THE DT372

Basic Features

The DT372 wireless tablet integrates a bright and responsive touch display, 1 USB port, and embedded networking elements such as wireless LAN, Bluetooth or optional 3G. The primary device is complemented by a suite of accessories, including battery expansion, docking cradles, and carrying cases, for a comprehensive user experience.



A DT372 typically integrates an 802.11a/b/g/n wireless LAN (WLAN) adapter that may connect to other wireless devices or access points. If your DT372 does not come with such a network adapter, please consult your device provider to establish the desired network connectivity.


OPERATION

Battery Replacement

The DT372 has a swappable battery on the back for continuous operations.

When the currently attached battery power gets very low, either turn off the DT372 to replace the current battery with a fully charged battery, or follow the instructions below.

- To replace the battery while the DT372 is powered on, press leftmost button  on the front panel. A window will open on the screen (Picture 1).
- Press “Yes” to enter Suspend mode and replace the battery.
- Wait for the blue LED light to go off before removing the battery.
- To remove the drained battery, push up on the right-side tab (Picture 2).
- Remove the drained battery, and insert a fully charged battery. When the charged battery is secure the right-side tab will click back into position.
- When the battery is replaced, press the  Power button to resume.



Picture 1



Picture 2

NOTE: If the tablet is put into Suspend mode and the battery is not replaced in a timely manner, or left off for a prolonged period of time, the tablet may shut down and any unsaved work may be lost.

NOTE: If the battery is replaced more than once during one session using the suspend-mode button, the tablet will shut down.

Powering ON and OFF

To activate the DT372, use the stylus to push and quickly release the Power Button. The display will come on in a few seconds. To put the DT372 in Standby mode, push and quickly release the Power Button. To turn the DT372 off for extended storage, power off the device safely using any software function that “shuts down computer” provided in the software operating system.

NOTE: The battery packs shipped with your device may be low in power—please use the AC-DC adapter with the DT372 when setting up the device for the first time to fully charge the internal battery pack.

NOTE: When the battery pack(s) is (are) charging, the blue-colored Battery LED should blink slowly. If plugging in the AC-DC adapter does not trigger this blinking activity and the LED stays dark, the battery pack(s) may have been drained substantially. Try unplugging/ replugging the AC-DC adapter to the DT372 a few times to activate the charging process.

NOTE: To conserve power, use (push and quick release) the Power Button to put the device in “Standby” mode while not in use. Pushing briefly on the same button will wake up the system within seconds.

NOTE: Avoid using the Power Button (“hold 4+ seconds” feature) to turn off the device—this form of hardware shutdown is intended to be a means of recovery from device lockups, and not as normal operation.

Start Up

If the power up (from Standby or otherwise) is successful, the appropriate interface will be displayed after a launch sequence of several seconds. The wireless LAN connection may take 10-15 seconds to be established.

Configuring the DT372

The device may be configured using the utilities and methods dictated by the software operating system. The DT372 should be configurable for various properties such as user profiles, network features, and several system elements.

DT372 with Windows XP



- A Calibration
- B Button Management

DT372 with Windows 7



- C Wireless Network Settings
- D Battery and Power Meter

Calibration

The touch display for the DT372 is calibrated before shipping. In the event that the calibration has been modified or is unsatisfactory, the respective calibration routines (e.g., PenMount (PM) for Windows XP) to calibrate the touch interface may be used. Such applications are typically executed through touch input via Stylus or through mouse click via a USB mouse.

Wireless Networking

Wireless LAN

The DT372 is often delivered with an embedded (user-inaccessible) 802.11a/b/g/n WLAN adapter equipped with a hidden custom antenna.


- Through the support of typical WLAN adapters, the DT372 should be able to detect all 802.11 access points in the vicinity for you to select the access point of your choice for connection.
- The SSID and WEP/WPA/WPA2 (if enabled) parameters on the DT372 and the access points have to match. The SSID is case-sensitive and it is recommended that you enable WEP/WPA/WPA2 encryption (or advanced alternatives) for secure access.
- When WEP/WPA/WPA2 is enabled, you may need to consult your network administrator or your networking equipment literature to properly configure associated settings such as Authentication mode, etc.
- Refer to the access point operating manuals for setting up the 802.11 access points.

Bluetooth

The DT372 features a built-in Bluetooth adapter that operates on the Microsoft Windows Bluetooth protocol. The Bluetooth configuration application is invoked from the System Tray or from the Control Panel. Follow the instructions and options provided within the application to configure and invoke Bluetooth connectivity with the corresponding peripherals.

NOTE: Bluetooth devices or accessories that are not compatible with the Microsoft Windows Bluetooth protocol may not work with the DT372.

Button Management

Where supported by software, many of the hard buttons on the DT372 are programmable to perform a function of the user's choice. The exception is the Power Button and the SAS Button. To activate the button re-assignment application, invoke the Button Manager application, e.g., in Windows XP Embedded .

Brightness Control

Where supported by device firmware and software, a hard button may be engaged to manipulate the display brightness. Press the System Utility Menu button (Button 5) on the front of the DT372. The System screen will display a Brightness control section with up and down arrows that can be activated with the stylus.

Battery and Power Management

The DT372 is equipped with a removable 3760mAh Li-Ion battery pack that is capable of supporting approximately 3 - 4 hours of continuous operation. The period between battery recharges can be significantly lengthened by putting the device into Standby mode through the Power Button (see Buttons Function Table) whenever the device is not in use. Depending on the operating software, the DT372 may also be configured to enter various power-saving modes via the Power Button or through timed entry.

Charging Cradle

The DT372 is complemented by an optional Desktop Cradle or Vehicle/ Wall Mount Cradle for support, pass-through charging, and connection to a range of USB peripherals, including keyboard and mouse. The Cradle offers the following interfaces: a DC-in port for the AC-DC adapter, an Ethernet port and USB ports. Always seat the DT372 securely onto the cradle. The cradle must be powered by the AC-DC adapter for the Ethernet and USB ports to function. The battery packs on the DT372 may be recharged by connecting the AC-DC adapter directly to the DC-in port on the DT372 or through the DC-in port on the Cradle while the DT372 is docked to the Cradle.

USING THE DT372

Memory & Storage configuration

The DT372 is available with 2GB memory configuration. Storage options currently range from 2GB to 32GB flash memory.

Peripherals Support

Through its USB ports, the DT372 supports a wide range of USB-based peripherals. These peripherals are applicable for software installation, applications storage, data storage, and system software recovery and updates. The DT372 is also compatible with custom mountable cradle options. These securable and mountable cradles provide an interface to VESA mounts and arms, and to ports that may include USB, Ethernet and pass-through power.